

Reference: GEO R73 v1.2

UAS GEOZONE ENTRY REQUIREMENTS FOR EBR-73

GEOZONE MANAGEMENT (to apply for flight authorization)		
Sint-Truiden AD Commander	ebst.geozonemanager@droneport.eu	
Sint-Truiden AD Commander	+32 (0) 11 58 09 89	
Online information:	https://droneport.eu/onbemande-luchtvaart/vluchtgebieden/ebr-73/	
Online Platform	https://skyman.lu/ebst/	

Geozone part of EBR-73; BVLOS operation			
Reference coordinates	1. 50°48′22″N 005°13′56″E	Zone height	2000ft AMSL or
	2. 50°46′57″N 005°15′55″E		1750ft AGL
	3. 50°43′55″N 005°15′45″E	UA Max height	1900ft AMSL
	4. 50°46′22″N 005°08′38″E	allowed	1650 ft AGL
ARC	ARC-a as defined by the	GRC	Within AD-perimeter:
	Geozone Manual		max. 4
			Outside AD-perimeter:
			depending on operator
Ground buffer	50 m	Air buffer	100 ft
Sensitive areas	Highways	Prohibited areas	
	Villages		Demulated areas
	Religious buildings		Populated areas ¹
	Cemetaries		
Dangerous areas	Chemical factories (yellow		
	mark)		
Possible Time of Activity	By NOTAM 24h in advance		

UAS REQUIREMENTS	Open	Specific	Certified
UAS Class	C0-C4	C5-C6	N/A
OR			
Mass	<150kg	Not applicable	According
			certification
Return to home	Х	X	According
Or system to prevent UA from leaving area			certification
Geofence set to remain within reserved zone	Х	Х	According
Or system to prevent UA from leaving area			certification
UA User Manual present	X	X	According
			certification
Remote ID	Х	X	According
			certification

¹ (unless operational authorisation obtained)



Reference: GEO R73 v1.2

OPERATOR REQUIREMENTS				
	Open	Specific		
	A1/A2/A3	STS	PDRA	SORA
Airspace	To be reserved through online platform	To be reserved through online platform	To be reserved through online platform	To be reserved through online platform
UA	Demonstrate compliance* by submitting relevant data in airspace reservation tool	Demonstrate compliance* by submitting relevant data in airspace reservation tool	Demonstrate compliance* by submitting relevant data in airspace reservation tool	Demonstrate compliance* by submitting relevant data in airspace reservation tool
Pilot	A1/A3 or A2;	Compliance with STS	Compliance with PDRA demonstrated	Compliance with SORA demonstrated
OPERATIONAL AUTHORISATION	Aware of operational limitations	DECLARATION ONLY (with receipt)	PDRA requires an operational authorisation from the Belgian Civil Aviation Authority	SORA requires an operational authorisation from the Belgian Civil Aviation Authority

^{*=} UAS Requirements

Operational Requirements for the operator			
Weather minima:	Min. visibility 5 km min. cloudbase 1500ft	Max. fire state level	G Y X
Take-Off Pos	If on RWY; expedite turn into EBR72	Take-Off Direction	Active RWY direction
Landing	If for RWY; expedite circuit	Landing direction	Active RWY direction
Hover	N/A	Two-Way Communication	Required Private Mobile Radio with EBST TWR or Brustem Radio (AIP EBST AD 2.18) or telephone EBST TWR
Flight conditions	VLOS: OPEN & SPEC CAT BVLOS: SPEC CAT	Means of fire extinguishing	For UAS fires and additional means for ground fires.
Mandatory Safety equipment provided by operator	First-aid kit - Fire Extingui High visibility jacket worn		



Important Telephone Numbers			
Sint-Truiden TWR	+32(0)11 58 09 89	Fire	112 or +32 (0) 67 41 18 30
Sint-Truiden TWR	+32 (0) 473 97 61 99	Police	101 or +32 (0) 67 88 92 11

Emergency Procedures	
Loss of communication (TWR)	Land immediately and contact EBST TWR
Loss of navigation	Initiate Return-to-Home and contact EBST TWR
Fly away	Monitor direction, height and speed.
	Contact EBST TWR
Fire	Contact EBST TWR to inform Fire Department
Public Encroachment	Observer to secure area. Land if necessary.
Aircraft intruder	Decreasing maximum height to minimum safe height in
	accordance with risk analysis.
Deteriorating weather	Come back to land ASAP, coordinate with EBST TWR

EBR 73

